User's Manual

FlexScan® L675

Color LCD Monitor

SAFETY SYMBOLS

This manual uses the safety symbols below. They denote critical information. Please read them carefully.



WARNING

Failure to abide by the information in a WARNING may result in serious injury and can be life threatening.



CAUTION

Failure to abide by the information in a CAUTION may result in moderate injury and/or property or product damage.



Indicates a prohibited action.



Indicates to ground for safety.

Copyright© 2000 by EIZO NANAO CORPORATION. All rights reserved. No part of this manual may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, or otherwise, without the prior written permission of Eizo Nanao Corporation.

Eizo Nanao Corporation is under no obligation to hold any submitted material or information confidential unless prior arrangements are made pursuant to Eizo Nanao Corporation's receipt of said information. Although every effort has been made to ensure that this manual provides up-to-date information, please note that EIZO monitor specifications are subject to change without notice.

ENERGY STAR is a U.S. registered mark.

Apple and Macintosh are registered trademarks of Apple Computer, Inc.

VGA is a registered trademark of International Business Machines Corporation.

DPMS is a trademark and VESA is a registered trademark of Video Electronics Standards Association.

Windows is a registered trademark of Microsoft Corporation.

ScreenManager, PowerManager and *i*·Sound are trademarks of

Eizo Nanao Corporation.

FlexScan and EIZO are registered trademarks of Eizo Nanao Corporation.



As an ENERGY STAR® Partner, Eizo Nanao Corporation has determined that this product meets the ENERGY STAR guidelines for energy efficiency.


TABLE OF CONTENTS

\triangle	PRECAUTIONS	4
1.	INTRODUCTION	10
2.	2-1. Before connecting	14
3.	ScreenManager 3-1. How to use the ScreenManager	18 19
4.	ADJUSTMENT 4-1. Screen Adjustment 4-2. Displaying the low resolutions 4-3. Color adjustment 4-4. Power-save Setup	22 27
5.	MAKING USE OF USB (Universal Serial Bus)	33
6.	CONNECTING TWO PCs to THE MONITOR	35
7.	ATTACHING AN ARM STAND	37
8.	TROUBLE SHOOTING	39
9.	CLEANING	43
10.	SPECIFICATIONS	44
11.	GLOSSARY	46
12.	INDEX	48
ΑP	PENDIX	i

IMPORTANT

- This product has been adjusted specifically for use in the region to which it was originally shipped. If operated outside the region to which it was originally shipped, the product may not perform as stated in the specifications.
- To ensure personal safety and proper maintenance. Please read this section and the caution statements on the unit (refer to the figure below).

[Location of the Caution Statements]



(Shown only when removing the original stand)

WARNING

If the unit begins to emit smoke, smells like something is burning, or makes strange noises, disconnect all power connections immediately and contact your dealer for advice.

Attempting to use a malfunctioning unit can be dangerous.

Do not dismantle the cabinet or modify the unit.
Dismantling the cabinet or modifying the unit may result in electric shock or burn.



Refer all servicing to qualified service personnel.

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards.

A WARNING

· Keep small objects or liquids away from the unit.

Small objects accidentally falling through the ventilation slots into the cabinet or spillage into the cabinet may result in fire, electric shock, or equipment damage. If an object or liquid falls/spills into the cabinet, unplug the unit immediately. Have the unit checked by a qualified service engineer before using it again.



Place the unit on a strong, stable surface.


A unit placed on an inadequate surface may fall, resulting in injury or equipment damage. If the unit falls, disconnect the power immediately and have the unit checked by a qualified service engineer before using it again. Using a unit after it has been dropped may result in fire or electric shock.



Set the unit in an appropriate location.

Not doing so may cause damage and could result in fire or electric shock.

- * Do not place in outdoors.
- * Do not place in the transportation system (ship, aircraft, trains, automobiles, etc.)
- * Do not install in a dusty or humid environment.
- * Do not place in a location where steam can have direct contact with the screen.
- * Do not place near heat generating devices or a humidifier.





 Use the enclosed power cord and connect to the standard power outlet of your country. Be sure to remain within the rated voltage of the power cord.

Not doing so may cause in fire or electric shock.

A WARNING

To disconnect the power cord, grasp the plug firmly and pull.

Never tug on the cord, doing so may cause damage and could result in fire or electric shock.





The equipment must be connected to a grounded main outlet. Failure to do this may reslut in an electric shock.



- Use the correct voltage.
 - * The unit is designed for use with a specific voltage only. Connection to another voltage than specified in this User's Manual may cause fire, electric shock, or other damage.
 - * Do not overload your power circuit, as this may result in fire or electric
 - * For proper connections of the power cord, be certain to plug the power cord to the provided unit connector and directly to a wall outlet. Not doing so may result in fire or electric shock.
- Handle the power cord with care.
 - * Do not place the cord underneath the unit or other heavy objects.
 - * Do not pull on or tie the cord.

If the power cord becomes damaged, stop using it. Use of a damaged cord may result in fire or electric shock.



- Never touch the plug and power cord if it begins to thunder.

 Touching them may result in electric shock.
- When attaching an arm stand, please refer to the user's manual of the arm stand and install the unit securely with the enclosed screws.

Not doing so may cause the unit to come unattached, which may result in injury or equipment damage. When the unit is dropped, please ask your dealer for advice. Do not continue using a damaged unit. Using a damaged unit may result in fire or electric shock. When reattaching the tilt stand, please use the same screws and tighten them securely.

A WARNING

Do not touch a damaged LCD panel directly with bare hands.

The liquid crystal which leaks from the panel is poisonous if it enters the eyes or mouth. If any part of the skin or body comes in direct contact with the panel, please wash thoroughly. If some physical symptoms result, please consult your doctor.



Follow local regulation or laws for safe disposal.

The backlight of the LCD panel contains mercury.

A CAUTION

Handle with care when carrying the unit.

Disconnect the power cord, cables and remove the optional *i*-Sound sound unit (if applicable) when moving the unit. Moving the unit with the cord attached is dangerous. It may result in injury or equipment damage.

* When handling the unit, grip the bottom of the unit firmly with both hands ensuring the panel faces outward before lifting. Then, do not grasp the LCD panel.



Dropping the unit may result in injury or equipment damage.

- Do not block the ventilation slots on the cabinet.
 - * Do not place books or any other papers on the ventilation slots.
 - * Do not install the unit in a closed space.
 - * Do not use the unit laying down or upside down.

Using the unit in these ways blocks the ventilation slots and prevents proper airflow, leading to fire or other damage.



A CAUTION

Do not touch the plug with wet hands.

Touching the plug with wet hands is dangerous and can cause electrical shock.

Use an easily accessible power outlet.

This will ensure that you can disconnect the power quickly in case of a problem.



Periodically clean the area around the plug.

Buildup of dust, water, or oil on the plug may result in fire.

Unplug the unit before cleaning it.

Cleaning the unit while it is plugged into a power outlet may result in electric shock.

If you plan to leave the unit unused for an extended period, disconnect the power cord from the wall socket after turning off the power switch for the safety and the power conservation.

Suggestions for Maximizing Comfort

- To lessen the chance of possible injury and to increase your comfort and productivity while you operate the unit, we suggest the followings:
 - * Avoid less favorable body positioning. Sit back on the chair with your back straight.
 - * Adjust the height of the chair so that the both soles touch the floor.
 - * Adjust the height of your chair, unit, or keyboard so that you can keep your wrists straight while typing.
 - * Set the unit slightly below eye level.
- Adjust brightness of the screen depending on the brightness of your environment. Too dark or too bright of a screen can cause eye strain.
- Be sure to take adequate rests. A 10-minute rest period each hour is suggested.

LCD Panel

- The screen may have defective pixels. These pixels may appear as slightly light or dark area on the screen. This is due to the characteristics of the panel itself, and not the product.
- The backlight of the LCD panel has a fixed life span.

 When the screen becomes dark or begins to flicker, please contact your dealer.
- Do not press on the panel or edge of the frame strongly, as this will result in damage to the screen. There will be prints left on the screen if the pressed image is dark or black. If pressure is repeatedly applied to the screen, it may deteriorate or damage your LCD panel. Leave the screen white to decrease the prints.



Do not scratch or press on the panel with any sharp objects, such as a pencil or pen as this may result in damage to the panel. Do not attempt to brush with tissues as this may scratch the LCD panel.

1. INTRODUCTION

Thank you very much for choosing an EIZO Color LCD Monitor.

1-1. Features

- DVI p.46) Digital input (TMDSp.47) compliance (DVI-I x 2)
- 1280 x 1024 resolution

Horizontal scanning frequency of 27-82 kHz

Vertical scanning frequency of 50-85 Hz (1280 x 1024 ~75Hz)

Vertical (Digital) of 60Hz (VGA text: 70Hz)

- Auto Adjustment compliant and original "Picture Adjustment Program" software included
- Smoothing function incorporated for the adjustment of an enlarged image
- ColorManagement function incorporated
- USB (Universal Serial Bus) hub supported
- The height adjustable stand incorporated
- Ultra slim bezel incorporated
- The Portrait/Landscape display capability

1-2. Package Contents

Please contact your local dealer for assistance if any of the listed items are missing or damaged.





Power Cord



 Signal Cable (FD-C04)



 Signal Cable (FD-C16)



• EIZO LCD Utility Disk



User's Manual



Quick Reference



• Warranty Registration Card




NOTE

Please retain the packing materials for future transference.

1-3. Controls & Connectors

Front




- Main Power Switch (1)
- Input Signal Selection Button (2)
- Auto Adjustment Button (3)
- (4) **Enter Button**
- (5) **Control Buttons**
- (6) Power Button
- (7) Power Indicator*1

Indicated color	Power-on status
Green	Power is on
Yellow	Power save mode
Flasing Yellow	Power save mode
	Digital only
Slowly flashing Yellow	Power is off (Main power is on)

ScreenManager™ (8)

^{*1} Regarding the power indicator for the "Off Timer", see page 21.

Rear



- (9) Height Adjustable Stand (Detachable) *2
- (10) DVI-I Input Connector x 2
- (11) Power Terminal Cover for the Optional Peripheral
- (12) USB Port (4 Downstream)
- (13) USB Port (1 Upstream)
- (14) Power Connector
- (15) Security Lock Slot*3
- *2 The LCD monitor has the capability of the Portrait/Landscape display. For the Portrait display, use the software for the portrait.
 - The LCD monitor can be used with an optional arm stand by removing the stand (see page 37).
- *3 Allows for connection of a security cable. This lock supports Kensington's MicroSaver security system. For further information, please consult:

Kensington Technology Group 2855 Campus Drive, San Mateo, CA 94403 USA 800-650-4242, x3348

Intl: 650-572-2700, x3348 / Fax: 650-572-9675

http://www.kensington.com

2. CABLE CONNECTION

2-1. Before connecting

Before connecting your monitor to the PC, change the display screen settings (resolution and frequency) in accordance with the charts below.

Analog Input

Resolution	Frequency	Remarks
640 x 480	~ 85 Hz	VGA, VESA
640 x 480	66.67 Hz	Apple Macintosh
720 x 400	70 Hz	VGA Text
800 x 600	~ 85 Hz	VESA
832 x 624	75 Hz	Apple Macintosh
1024 x 768	~ 85 Hz	VESA
1152 x 864	75 Hz	VESA
1280 x 960	~ 85 Hz	Apple Macintosh
1280 x 1024	~ 75 Hz	VESA

NOTE

 About Plug & Play of the monitor When your computer and display support VESA DDC, the suitable resolution and the refresh rate are set by just plugging your display into the computer without any manual settings. When your computer system supports Plug & Play, the Display Information File is not required except for installing the Color Profile.

Digital Input

Only the following resolutions with frequency can be displayed on this model.


Resolution	Frequency	Remarks
640 x 480	60 Hz	VGA
720 x 400	70 Hz	VGA Text
800 x 600	60 Hz	VESA
1024 x 768	60 Hz	VESA
1280 x 960	60 Hz	VESA
1280 x 1024	60 Hz	VESA


2-2. Connecting the signal cable

NOTE

- Be sure that the power switches of both the PC and the monitor are OFF.
- **1.** Plug the signal cable into the DVI-I connector at the rear of the monitor and the other end of the cable into the video connector on the PC.

After connecting, secure the connection with the screw-in fasteners.





2. Plug the power cord into the power connector on the rear of the monitor.

WARNING


• Use the enclosed power cord and connect to the standard power outlet of your country. Be sure to remain within the rated voltage of the power cord.

Not doing so may cause in fire or electric shock.

3. Lead the power cord and signal cable into the cable holder at the rear of the monitor.

NOTE

- When housing the cables into the cable holder, lead them to the cable entrance side and pinch the projection to open the cable entrance.
- · The cables are recommended to lead with slight sag for the smooth motion of the stand.



4. Plug the other end of the power cord into a power outlet.

A WARNING

The equipment must be connected to a grounded main outlet.



Not doing so may cause in fire or electric shock.

5. Turn on the monitor's power and then switch on the PC's power. Whenever finished, turn off the PC and the monitor.


NOTE

• When turning on the monitor, the kind of the input signal (Signal 1 or 2/Analog or Digital) is displayed for a few seconds on the right top corner of the screen.

3. ScreenManager

3-1. How to use the ScreenManager

As shown on the display, the ScreenManager is used to adjust the LCD monitor. ScreenManager consists of main menus and sub menus. Adjustments are made using the Enter and Control buttons (up, down, right and left) located on the front panel.



1. Entering the ScreenManager

Push the Enter button once to display the main menu of the ScreenManager.



[Main Menu]

2. Making Adjustments and Settings

- (1) Select the desired sub menu icon using the Control buttons and push the Enter button. The sub menu appears.
- (2) Use the Control buttons to select the desired setting icon and push the Enter button. The setting menu appears.
- (3) Use the Control buttons to make all required adjustments and push the Enter button to save the settings.

3. Exiting the ScreenManager

- (1) To return to the main menu, select the "Return" icon or push the down button twice, followed by the Enter button.
- (2) To exit the ScreenManager, select "Exit" icon and push the Enter button.

NOTE

• Double clicking the Enter button at any time also exits the ScreenManager menu.

3-2. ScreenManager Adjustments and Settings.

The following table shows all the ScreenManager's adjustment and setting menus. "*" indicates adjustments of analog input only and "**"indicates digital input only.

Main menu	Sub menu		Reference	
Screen	Clock*			
	Phase*			
	Position			
	Resolution			
	Smoothing		-	
	Contrast/Brightness	3	-	
	Signal Filter*		-	
Color-	Range Adjustment*		-	
Management	Standard Mode	Temperature	-	
Management	Custom Mode	Temperature	4. ADJUSTMENT(p.22)	
	Odstorriviode	Saturation	-	
		Hue	-	
		Gain	-	
		Save	-	
PowerManager	DVI DMPM**	Jave	-	
1 Owenvianager	VESA DPMS*		-	
	EIZO MPMS*		-	
Others	Screen Size		-	
Others	Border Intensity		-	
	Off Timer		Set the monitor's off timer to	
	On Time		on or off. (p.21)	
	Input Priority		Select the priority signal. (p.36)	
	Beep		Set the Monitor's beeper to on or	
			off. (p.45)	
	Menu Settings	Menu Size	Change the size of the menu.	
	Wierra Cottingo	WOTA OIZO	Change the oize of the mona.	
		Menu Position	Adjust the menu position.	
		Menu Off Timer	Set the menu displaying time.	
		Translucent	Set the transparency of the	
			background.	
		Rotate	Change the orientation of the	
			ScreenManager.	
	Reset		Return to the factory default	
			settings. (p.45)	
Information	Information		Review the ScreenManager's	
			settings, model name, Serial	
			Number and usage time*1.	
Language	English, German, F	rench. Spanish	Select the ScreenManager's	
	Italian, Swedish and Japanese		language.	
	- Island Gradien and			

^{*1} Due to the inspection on the factory, the usage time may not "0 hour" at purchasing.

3-3. Useful Functions

Adjustment Lock

Use the "Adjustment Lock" function to prevent any accidental changes.

Locked function	Auto adjustment button adjustments and settings in the ScreenManager.
Unlocked function	Adjustment of contrast and brightness by the control buttons.
	Input signal selection button

• To lock

Press on the Auto adjustment button while switching on the monitor's power button on the front panel.

To unlock

Switch off the monitor's power by the power button on the front panel, then hold down the Auto adjustment button once again and turn the power back on.

EIZO Logo Disappearing function

When switching on the power button on the front panel, the EIZO logo is displayed for a while. If you desire to undisplay this logo, use this function.

• To undisplay

Switch off the monitor's power by the power button on the front panel. Turn the power back again with pressing the enter button on the front panel.

• To display again

Switch off the monitor's power by the power button on the front panel. Turn the power back again with pressing the enter button on the front panel.

Off Timer

The off timer function causes the monitor to automatically enter a power off state after a predetermined amount of time has lapsed. This function was created to reduce afterimage p.46) characteristics that are particular to LCD monitors when the monitor screen is left on for a long period without use.

[Procedure]

- (1) Select "Off Timer" in the ScreenManager "Others" menu.
- (2) Select "Enable" and press the right and left buttons to adjust the "On Period" (1 to 23 hours).

[Off timer system]

PC	Monitor	LED
On Period (1H~23H)	Operation	Green
Last 15 min. in "On period"	Advance Notice *1	Green Flashing
"On period" expired	"Power Off" Mode	Flashing yellow slowly

^{*1}Advance notice (LED flashing green) will be given 15 minutes before the monitor automatically enters the "Power Off" mode. To delay entering the "Power Off" mode, press the power button during the advance notice period. The monitor will continue to operate for an additional 90 minutes.

Press the power button to return to a normal screen.

NOTE

 The off timer function works while the PowerManager is active, but there is no advance notice before the monitor's power is switched off.

4. ADJUSTMENT

4-1. Screen Adjustment

NOTE

 Allow the LCD monitor to stabilize for at least 20 minutes before making image adjustments.

When connecting the DVI-I cable for digital input, please see page 26.

Adjustment Procedure for Analog Input

Screen adjustments for the LCD monitor should be used in suppressing screen flickering and also for adjusting the screen to its proper position. There is only one correct position for each display mode. It is also recommended to use the ScreenManager function when first installing the display or whenever changing the system. For convenience, an easy set-up Program installed on the utility disk to assist in the set-up procedure is provided.

1. Push the Auto adjustment button on the front panel.

The message "Your setting will be lost, if you press again now." appears and remains on the screen for 5 seconds. While the message is on the screen, push the Auto adjustment button again to automatically adjust the clock, phase, screen position and resolution. If you do not wish to do adjust the screen, do not push the Auto adjustment button again.

If the appropriate screen can not be made by using the Auto adjustment button, adjust the screen through the following procedures.

2. Install the "Screen adjustment program".

Having read the "readme.txt" file, install and run the "Screen adjustment program" in the enclosed EIZO LCD utility disk.

Step by step adjustment is provided by the wizard guide.

NOTE

• If the user's operating system has no utility disk (e.g. OS/2), we recommend setting the desktop pattern to that as shown in the diagram below.



- **3.** Adjust by using "Screen" menu in the ScreenManager.
 - (1) Vertical bars appear on the screen.
 - → Use the "Clock" p.46) adjustment

Select the "Clock" and eliminate the vertical bars by using the right and left of the control buttons. Do not continuously press the control buttons, as the adjustment value will change quickly and make it difficult to locate the most suitable adjustment point.


If the horizontal flickering, blur or bars appear, proceed to "Phase" adjustment as follows.



NOTE

- When adjusting the "Clock," the horizontal screen size will also change.
- (2) Horizontal flickering, blurring or bars appear on the screen.
 - → Use the "Phase" p.47) adjustment.

Select the "Phase" and eliminate the horizontal flickering, blurring or bars by using the right and left buttons.



NOTE

• Horizontal bars may not completely disappear from the screen depending on the PC.


(3) The screen position is incorrect.

→ Use the "Position" adjustment.

The correct displayed position of LCD monitor is decided because the number and the position of the pixels are fixed. The "Position" adjustment moves the image to the correct position.

Select "Position" and adjust the position of the upper left corner of the image by using the up, down, right and left buttons in order to align the screen.

If vertical bars of distortion appear after finishing the "Position" adjustment, return to "Clock" adjustment and repeat the previously explained adjustment procedure ("Clock" → "Phase" → "Position").




(4) Screen image is smaller or larger than the actual screen images.

→ Use the "Resolution" adjustment.

Adjustment is needed when the input signal resolution and the resolution now being displayed is different.

Select "Resolution" and confirm if the resolution now being displayed is the same as the input resolution. If it is not, adjust the vertical resolution using the up and down button and adjust the horizontal resolution using the right and left buttons.

Smaller than the actual screen images.



4. Set the Output signal range (Dynamic Range) of the signal.

→ Use the "Range Adjustment". p.47)

This controls the level of output signal range to display the whole color gradation (256 colors). Select the "Range Adjustment" in the color menu.

[Auto]

Push the Auto adjustment button on the front panel while displaying the "Range adjustment" menu to automatically adjust the range. The screen blanks for a moment, and adjusts the color range to display the whole color gradation of the current output signal.

NOTE

Pressing Auto adjustment button while displaying the contrast/brightness
adjustment screen (appeared by pressing the control buttons directly) adjusts the
range automatically.

5. Set the Contrast of the screen.

→ Use the "Contrast" adjustment.

This controls the brightness for the each color (red, blue and green) at a same time.

Select "Contrast/Brightness" in the screen menu and adjust by using the right and left buttons.

NOTE

• Percentage over the 100 % may cause undisplayable color tone.

6. Set the Brightness of the screen.

→ ○ Use the "Brightness" adjustment.

This controls the brightness for the entire screen. The brightness of the entire screen is controlled by changing the brightness if the backlight.

Select "Contrast/Brightness" in the screen menu and adjust by using the up and down buttons.

NOTE

• Directly pressing the control buttons also adjusts the contrast and brightness. Press the "Enter" button to save and exit the settings after the adjustment.

Digital Input

The monitor displays the digital input image correctly based on its pre-setting data. However, if the image position is not incorrect or larger than the actual image screen, please adjust the following adjustment items using the "Screen" menu of the ScreenManager.

- **1.** The screen position is incorrect.
 - → Use the "Position" adjustment.

See page 24.

- **2.** Screen image is smaller or larger than the actual screen images.
 - → Use the "Resolution" adjustment.

See page 24.

- **3.** Set the Contrast of the screen.
 - → Use the "Contrast" adjustment. See page 25.
- **4.** Set the Brightness of the screen.
 - → O Use the "Brightness" adjustment.

See page 25.


4-2. Displaying a low resolutions


- **1.** Enlarge the screen size when displaying a low resolution.
 - → Select "Screen Size"


Select the "Screen Size" in the others menu and select the screen size by using the up and down buttons.

• Full	Displays the picture on the screen in full, irrespective of the picture's resolution. Since the vertical resolution and the horizontal resolution are enlarged at different rates, some images may appear distorted.
• Enlarged	Displays the picture on the screen in full, irrespective of the picture's resolution. Since the vertical resolution and horizontal resolution are enlarged at same rates, some horizontal or vertical image may disappear.
Normal	Displays the picture at the actual Screen resolution.

Example: Displaying 1024 x 768







2. Smooth the blurred texts of the enlarged screen.

→ Use the "Smoothing" adjustment.

Select the suitable level from $1 \sim 5$ (Soft \sim Sharp).


Select "Smoothing" in the screen menu and adjust by using the right and left buttons.

NOTE

- "Smoothing" is disabled when the screen is displayed in the following resolution.
 - * 1280 x 1024
 - * The image size is doubled both in horizontally and vertically (i.e. 1280 x 960 enlarged from 640 x 480) to provide clear focus which does not require this function.
- **3.** Set the brightness of the black area surrounding the displayed image.
 - → Set the "Border Intensity"

In the "Enlarged" mode or "Full Screen" mode, the outer area (border) is usually black.

Select "Border Intensity" in the others menu and adjust by using the right and left buttons.




4-3. Color Adjustment

The "ColorManagement" menu in the ScreenManager enables to change the color of the screen.

Before the Color adjustment

- Allow the LCD monitor to stabilize for at least 20 minutes before making color adjustments.
- After finishing each adjustment in the custom mode, select "Save" icon to resister the adjustment. Otherwise, the adjustment will be lost.
- The adjustment values represent the current level within the specific adjustment only. They are available only as a reference tool. (To create a uniform white or black screen, the percentages for each will probably not be the same.)
- In the analog input, perform the "Range Adjustment" (p.25) before making the color adjustments. The gradation pattern like below is recommended for the "Range Adjustment".



1. To change the color tone of the white.

→ K Set the "Temperature".p.46)

The "Temperature" can be set from 4,000 K to 10,000 K, in 500 K increments (including 9,300 K). The default setting is "OFF".

To resister the adjustment in the custom mode, select the "Save" icon and then push the enter button.

NOTE

- Setting the temperature under 4,000 K or over 10,000 K invalidates the color temperature setting. (The color temperature's setting turns "OFF".)
- Adjusting the "Gain" (p. 30) invalidates the color temperature setting. (The color temperature's setting turns "OFF".)

2. To change the saturation.

→ Use the "Saturation" adjustment.

The "Saturation" can be selected from -16 to 16. Setting the minimum level (-16) turns the image to the monochrome.

To register the adjustment, select the "Save" icon and then push the enter button.

NOTE

• The "Saturation" adjustment may cause undisplayable color tone.

3. To change the flesh color, etc.

→ ((a) Use the "Hue" adjustment.

The "Hue" can be selected from -20 to 20.

To register the adjustment, select the "Save" icon and then push the enter button.

NOTE

• The "Hue" adjustment may cause undisplayable color tone.

4. To adjust each color (red, green and blue).

→ (Use the "Gain" p.47) adjustment.

By adjusting the red, green and blue color tones for each mode, custom colors can be defined.

The 100 % indicates unadjusted condition.

Display a white or gray background image and adjust the "Gain".

To register the adjustment, select the "Save" icon and then push the Enter button.

NOTE

· Adjusting the "Gain" invalidates the color temperature setting. (The color temperature's setting turns "OFF".)

4-4. Power-save Setup

NOTE

- Do your part to conserve energy, turn off the monitor when you are finished using it.
 Disconnecting the monitor from the power supply is recommended to save energy completely.
- Even if the monitor is in a power saving mode, USB compliant devices function when they are connected to the monitor's USB (both the upstream and the downstream ports). Therefore, power consumption of the monitor will change according to the connected devices even if the monitor is in a power saving mode.

Analog Input

This monitor complies with the VESA DPMS p.47) standard and adopts a power saving method, EIZO MPMS p.46), which works with a blank screen (totally black screen) like "Blank Screen" ScreenSaver software.

1. To use the PC's power saving system (VESA DPMS).

[Procedure]

- (1) Set the PC's power saving settings.
- (2) Select "VESA DPMS" in the "PowerManager" menu.

[Power saving system]

PC		Monitor	LED
On		Operation	Green
Power saving mode	STAND-BY SUSPEND OFF	Power saving	Yellow

Operate the mouse or keyboard to return to a normal screen.

2. To set the power save with ScreenSaver software (EIZO MPMS).

[Procedure]

- (1) Set the PC's appropriate ScreenSaver settings or blank the screen (totally black screen)
- (2) Select "EIZO MPMS" from the "PowerManager" menu.

[Power saving system]

PC	Monitor	LED
ON	Operation	Green
Blank the screen (ScreenSaver or Macintosh Energy Saver)	Power saving	Yellow

Operate the mouse or keyboard to return to a normal screen.

NOTE

• EIZO MPMS should be used with Macintosh "EnergySaver".

Digital Input

This monitor complies with the DVI DMPM ^{p.46)}.

[Procedure]

- (1) Set the PC's power saving settings.
- (2) Select "DVI DMPM" in the "PowerManager" menu.

[Power saving system]

PC	Monitor	LED
On	Operation	Green
Power saving	Power saving	Yellow
Off mode	Power saving*1	Flashing yellow (2 times for each)

^{*1} Power saving through the PC's off mode is only supported when "Manual" is selected on the ScreenManager's "Input Priority".

Operate the mouse or keyboard to return to a normal screen from the Power save mode of the PC.

Power on the PC to return a normal screen from the Off mode of the PC.

5. MAKING USE OF USB (Universal Serial Bus)


This monitor provides a hub which supports the USB standard. When connecting to a USB compliant PC or another hub, the monitor functions as a hub to which the USB compliant peripherals can be easily connected.

Required system environment

- PC equipped with USB ports or another USB hub connected to the USB compliant PC
- Windows 98/Me/2000 // Mac OS 8.5.1 or later
- USB cable / MD-C93 (Optional)
- The USB hub function may not work properly depending on the PC, OS or peripherals. Please consult the manufacturer of each device about the USB support.
- When the monitor is not on, the peripherals connected to the downstream ports will not operate.
- Even if the monitor is in a power saving mode, the devices connected to the monitor's USB ports (both the upstream and the downstream) will function.

Connecting to the USB HUB


- Do not connect the downstream port of the monitor to any peripherals until finishing the USB function.
- The followings are procedures for the Windows 98/Me/2000 and Mac OS.
- **1.** Connect the monitor to the PC with the signal cable (See page 15) first, then turn on the PC.
- **2.** Connect the upstream port of the monitor to the downstream port of the USB compliant PC or another hub by using the USB cable .



After connecting the USB cable, the USB function can be set up automatically.


3. After setting up, the monitor's USB hub is available for connecting USB compliant peripherals to the downstream ports of the monitor.


Example of connection:




6. CONNECTING TWO PCs to THE MONITOR

Two PCs can be connected to the monitor through the Signal 1 and the Signal 2 on the back of the monitor.








Selecting the active input

The Input signal selection button on the front panel can be used to select either Signal 1 or Signal 2 as the active input at any time. Every time the button is pressed, the input changes. When the switching the signal, the displaying signal kind (signal 1 or 2/Analog or digital) is displayed for a few seconds.



The priority input signal

This function is used to select which PC will have priority to control the monitor when utilizing two PCs. The monitor constantly checks the input signals and switches automatically in accordance with the "Input Priority" setting (see table below). Once a priority is set, whenever a change of signal is detected at the selected input, the monitor will switch the input to that signal.

In the case of only one signal being present at either input, the monitor automatically detects and displays that signal.

Priority setting	Performance
Signal 1	 If signals from both inputs are present, the monitor gives preference to Signal 1 in the following cases. When the power of the monitor is turned ON When the signal input to Signal 1 is changed even if active input was Signal 2.
Signal 2	 If signals from both inputs are present, the monitor gives preference to Signal 2 in the following cases. When the power of the monitor is turned ON When the signal input to Signal 2 is changed even if active input was Signal 1.
Manual	The monitor will not detect signals automatically in this mode. Select the active input by pressing the input signal selection button on the monitor's front panel.

NOTE

Regarding the power saving mode
 When the Signal 1 or Signal 2 is selected, the power saving mode of the monitor activates only if both PCs are in power saving mode.

7. ATTACHING AN ARM STAND


The LCD monitor can be used with an arm stand by removing the tilt stand and attaching the arm stand to the LCD monitor.

NOTE

- Use an arm stand that satisfies the followings.
 - When using the LCD monitor with an arm stand, the arm stand must be VESA approved:
 - * Use an arm stand with a 100 mm x 100 mm hole spacing on the arm mounting pad.
 - * Use an arm stand that is able to support an object weighing 13.5 kg.
 - TÜV/GS approved arm stand.
 - Use an arm stand with sufficient stability (mechanical firmness) to support the weight of the monitor.
 - Use an arm stand remaining that position where it is manually moved.
 - Use an arm stand with the ability to tilt the monitor forward and backward.
- Please connect cables after attaching an arm stand.

Setup Procedure

- **1.** Lay the LCD monitor down. Do not scratch the panel.
- **2.** Remove the stand by loosening the screws. (4 pcs of M4 \times 16 Ni/Fe)




3. Attach an arm stand to the LCD monitor securely.

WARNING

When attaching an arm stand, please refer to the user's manual of the arm stand and install the unit securely with the enclosed screws.

Not doing so may cause the unit to come unattached, which may result in injury or equipment damage. When the unit is dropped, please ask your dealer for advice. Do not continue using a damaged unit. Using a damaged unit may result in fire or electric shock. When reattaching the tilt stand, please use the same screws and tighten them securely.



NOTE

For the Portrait display, rotate the monitor clockwise and use the software for the portrait.

8. TROUBLESHOOTING

If a problem persists even after applying the suggested remedies, contact an EIZO dealer.

- \square No picture problems \rightarrow See No.1 ~ No.2
- ☐ Imaging problems → See No.3 ~ No.14
- ☐ USB problems→See No.19 ~ No.20
- ☐ Other problems→See No.15 ~ No.18

Problems	Points to check with possible solutions
1. No pictureIndicator status: Off	 □ Check that the power cord is correctly connected. □ If the problem persists, turn off the monitor power for a few minutes, then turn it back on and try again.
 Indicator status: Green Indicator status: Yellow Indicator status: Slowly flashing Yellow 	 □ Check the "Contrast and Brightness" settings. Minimum settings will cause screen to be blank. □ Try pressing a key on the keyboard, or clicking the mouse. (p.31) □ Try pressing the power button.
2. Following messages appear. Signal Check Signal 2 fH: 0.0kHz fU: 0.0Hz	These messages appear when the signal is not inputted correctly, even if the monitor functions properly. Error messages shown below will remain on the screen for 40 seconds. When the image is displayed correctly after a short time, there is no problem with the monitor. (Some PCs do not output the signal soon after powering on.) Check that the PC is turned ON. Check that the signal cable is properly connected to the PC or graphics board. Switch the signal input by pressing the input signal selection button on the front control panel.
•Whenever an error signal message appears, the signal frequency will be displayed in red. (Example) Signal Error Signal 2 fH: 110.7kHz fU: 75.0Hz	□ Use the graphics board's utility software to change the frequency setting. (Refer to the manual of the graphics board.)

Problems	Points to check with possible solutions
3. Display position is incorrect.	 □ Adjust the image position using the "Position". (p.24) □ If the problem persists, use the graphics board's utility software to change the display position if available.
4. Screen image is smaller or larger than the actual screen images.	☐ Adjust the resolution using the "Resolution". (p.24)
5. Vertical bars of distortion appear. (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely) (uncupylipedisodely)	□ Decrease the vertical bars using the "Clock". (p.23)
6. Horizontal bars of distortion appear.	□ Decrease the horizontal bars using the "Phase'. (p.23)
7. Letters and lines appear blurred.	☐ Adjust the blurred lines using "Smoothing". (p.28)
8. Distortion appears like the figure below.	☐ This happens when both composite (X-OR) input signal and separate vertical synchronizing signal are input. Please select one of the two.
9. The screen is too bright or too dark.	☐ Adjust the "contrast and brightness". (The backlight of the LCD monitor has a fixed life span. When the screen becomes dark or begins to flicker, please contact your dealer.)
10. Afterimages appear.	☐ When the screen image is changed after displaying the same image for a long period, an afterimage may appear. Use the "Off Timer" function and avoid keeping the screen on all the time. (p.21)

Problems	Points to check with possible solutions
11. The screen has defective pixels (e.g. slightly light or dark).	☐ This is due to the characteristics of the panel itself, and not the LCD product.
12. Fingerprints remain on the screen.	☐ Leaving the screen black may solve the problem.
13. The "Smoothing" can not be selected.	 □ "Smoothing" is disabled when the screen is displayed in the following resolution. • 1280 x 1024 □ The image size is doubled both in horizontally and vertically (i.e. 1280 x 960 enlarged from 640 x 480) to provide clear focus which does not require this function.
14. The noise appears on the screen.	☐ Change the mode in "Signal Filter" in the "Screen" Adjustment".
15. The utility disk is unable to be opened (for Macintosh only).	☐ Some Macintosh without PC-Exchange do not allow the utility disk to be opened. Please set the desktop pattern to every-other-dot before adjustment. (p.22)
16. • The Enter button does not operate.• The Auto adjustment button does not operate.	☐ The adjustment lock is probably on. To unlock: switch the LCD monitor off. Then, while pressing the Auto adjustment button switch, the power on. (p.20)
17. The Auto adjustment button does not work properly.	□ The Auto sizing function is intended for use on the Macintosh and on AT-compatible PC running Windows. It may not work properly in either of the following cases. When running an AT-compatible PC on MS-DOS (Not windows). The background color for the "wall paper" or "desktop" pattern is set to black. Some signals from a graphics board may not function properly.

Problems	Points to check with possible solutions
18. Frequency does not change after installing "Monitor information file" in the attached utility disk on Windows 95/98/Me/2000.	☐ Use the graphics board's utility software to change the input signal frequency.
19. USB function cannot be setup.	 □ Check that the USB cable is correctly connected. □ Check that the PC and OS are USB compliant. (For verification of USB support, consult the manufacturer of each system.) □ Check the PC's BIOS setting for USB. (For details, refer to the manual of the PC.)
20. PC is hung up. / The peripherals connected to the downstream ports do not operate.	 □ Check that the USB cable is correctly connected. □ Check the downstream ports by connecting the peripherals to other downstream ports. If the problem is solved by doing this, contact an EIZO dealer. □ Try executing the following methodRestarting the PC -Connecting the PC and peripherals directly If the problem is solved by doing this, contact an EIZO dealer. □ The power button of the APPLE keyboard does not operate if it is connected to the EIZO USB Hub. Please connect the keyboard directly with the PC. Refer to the instruction of the PC for details.

CLEANING

Periodic cleaning is recommended to keep the monitor looking new and to prolong its operation lifetime.

NOTE

· Never use thinner, benzene, alcohol (ethanol, methanol, or isopropyl alcohol), abrasive cleaners, or other strong solvents, as these may cause damage to the cabinet or LCD panel.



Cabinet

To remove stains, wipe the cabinet with a soft, lightly moistened cloth using a mild detergent. Do not spray wax or cleaner directly onto the cabinet.

LCD Panel

The LCD surface can be cleaned with a soft cloth, such as cotton or lens paper. If necessary, stubborn stains can be removed by moistening part of a cloth with water to enhance its cleaning power.

10.SPECIFICATIONS

[ran n t					
LCD Panel	46 cm (18.1 inch), TFT color LCD panel with Anti-				
	Glare Hard Coating				
	Viewing Angle: Horizontal: 160°, Vertical: 160°				
	(at Contrast Ratio ≥ 10)				
	Image Formation Time: approx. 78 ms				
Dot Pitch	0.280 mm				
Scan Frequency	Horizontal: 27 kHz - 82 kHz (Automatic)				
	Vertical: 50 Hz-85 Hz (Automatic)				
	$(1280 \times 1024 : up to 75 Hz)$				
	Vertical(Digital): 60Hz (VGA Text : 70Hz)				
Resolution	1280dots x 1024 lines				
Dot Clock (Max.)	135 MHz				
	108 MHz(Digital)				
Display Colors	16 milion colors (max)				
Display Area	359 mm (H) x 287 mm (V) (14.1" (H) x 11.3" (V))				
	(Viewable image size: 459 mm (18.1"))				
Power Supply	100-120/200-240 VAC±10%, 50/60 Hz, 0.8 A/0.4 A				
Power Consumption	Normal/Max.: 56 W/76 W*				
	Power Saving Mode: Less than 5 W				
	(When the USB hub is not connected)				
Input Connector	DVI-I x 2				
Input Signal	Sync: a) Separate, TTL, Positive/Negative				
	b) Composite, TTL, Positive/Negative				
	c) Sync on Green, 0.3 Vp-p, Negative				
	Video: 0.7 Vp-p/75 Ω, Positive				
	(Digital: TMDS (Single Link))				
Signal registration	28 (Factory preset: 23)(Digital: 5 (Factory preset: 0))				
Plug & Play	VESA DDC 2B				
Dimensions	399 mm (W)x423.5 mm (H:minimum)x208.5 mm (D)				
	(15.7" (W) x 16.7" (H) x 8.2" (D))				
Dimensions (without stand)	399 mm (W) x 328 mm (H) x 65 mm (D)				
	(15.7" (W) x 12.9" (H) x 2.6"(D))				
Adjustable Height	80mm (3.1")				
Weight	9.0 kg (19.8 lbs.)				
Weight (without stand)	5.5 kg (12.1 lbs.)				
Temperature	Operating: 0°C to 35°C (32°F to 95°F)				
	Storage: -20°C to 60°C (-4°F to 140°F)				
Humidity	30% to 80% R.H. Non-condensing				
USB specification					
USB standard	Rev. 1.1 complied self-powered hub				
Communication speed	12 Mbps (full), 1.5 Mbps (low)				
Downstream power supply					
USB ports	Upstream port x 1, Downstream port x 2				

^{*} With EIZO optional speaker & USB attached.

Default setting

Default setting are as follows:

ScreenManager menu	1	Analog Digital		
Contrast		100%		
Brightness		100%		
Smoothing		3	}	
ColorManagement	Color Mode	Stand	dard	
	Temperature	O:	ff	
PowerManager	owerManager		DVI DMPM	
Screen Size		Full Screen		
Input Priority		Signal 1		
Off Timer		Disa	ıble	
Menu Settings	Menu Size	Normal		
Menu Off Timer		45 seconds		
Веер		On		
Language		Eng	lish	

Beeper settings

Short beep	· ScreenManager item selected.			
	ScreenManager parameter adjusted to minimum or			
	maximum limit.			
	· Input signal selection button pressed.			
Long beep	· Auto Adjustment button pressed.			
	· ScreenManager data-save executed.			
4 short beeps	Monitor not connected correctly.			
	· PC turned off.			
	Monitor received unsupported signal frequency.			
2 short beeps every 15 sec.	Monitor is in the advance notice mode of the Off			
	Timer. The power will be off within fifteen minutes.			

11.GLOSSARY

Afterimage

The Afterimage is particular to LCD monitors when the monitor screen is left on for a long period without use. The "Afterimage" can be removed gradually by changing the displayed image.

Clock

With the analog input signal display, the analog signal is converted to a digital signal by the LCD circuitry. To convert the signal correctly, the LCD monitor needs to produce the same number clock pulse as the dot clock of the graphics system. When the clock pulse is not correctly set, some vertical bars of distortion are displayed on the screen.

Color Temperature (Temperature)

Color Temperature is a method to measure the white color tone, generally indicated in degrees Kelvin. At high temperatures the white tone appears somewhat blue, while at lower temperatures it appears somewhat red. Computer monitors generally give best performance at high temerature settings.

5000K: Slightly reddish white.

6500K: Warm-white tone, similar to white papaer or daylight.

9,300K: Slightly bluish white.

DVI

(Digital Visual Interface)

A digital flat panel interface. DVI can transmit digital data from the PC directly without loss with the signal transition method "TMDS". There are two kinds of DVI connectors. One is DVI-D connector for digital signal input only. The other is DVI-I connector for both digital and analog signal inputs.

DVI-DMPM

(DVI Digital Monitor Power Management)

The Power management system for the digital interface. The "Monitor ON" status (operation mode) and the "Active Off" status (power-saving mode) are indispensable for the DVI-DMPM as the monitor's power mode.

EIZO MPMS

EIZO MPMS, "EIZO Monitor PowerManager Signaling", also enables power saving on the monitor side. EIZO MPMS recognizes video signals from the PC when the PC is in a power saving mode, and reduces energy consumption of the monitor.

Gain Adjustment

Adjusts each color parameter for red, green and blue. The color of the LCD monitor is displayed through the color filter of the LCD panel. Red, green and blue are the three primary colors. The colors on the monitor are displayed by combining these three colors. The color tone can change by adjusting the illumination amount passed through each color's filter.

Phase

The phase adjustment decides the sampling timing point for converting the analog input signal to a digital signal. Adjusting the phase after the clock adjustment will produce a clear screen.

Range Adjustment

The Range Adjustment controls the level of output signal range to display the whole color gradation.

Resolution

The LCD panel consists of a fixed number of pixel elements which are illuminated to form the screen image.

The EIZO L675 consists of 1280 horizontal pixels and 1024 vertical pixels. At a resolution of 1280 X 1024, all pixels are used and the image is displayed as a full screen. At the lower display modes of 640 x 480 or 800 x 600, the images are displayed in the center of the screen using a smaller portion if the pixels.

TMDS

(Transition Minimized Differential Signaling) A signal transition method for the digital interface.

VESA DPMS

The acronym VESA stands for "Video Electronics Standards Association," and DPMS stands for "Display Power Management Signaling." DPMS is a communication standard that PCs and graphics boards use to implement power savings on the monitor side.

12.INDEX

Α		L	
	ADJUSTMENT 22		Language 19
	Adjustment Lock 20	М	0 0
	Afterimage 21,46	141	MAKING USE OF USB
	ATTACHING AN ARM STAND 37		(Universal Serial Bus) 33
В			Menu Off Timer 19
	Beep 19		Menu Position 19
	Beeper setting45	_	Menu Position19
	Before connecting14	0	
	Border Intensity 19, 28		Off timer 19, 21
	Brightness 19, 25,26		Others 19
_	Diigitaless 19, 29,20	Р	
С		_	Package Contents 11
	CABLE CONNECTION 14		Phase 19, 23, 47
	CLEANING 43		Pin Assignmentiv
	Clock 19, 23,46		Position 19, 24,26
	Color Adjustment 29		Power consumption 44
	ColorManagement 19, 29		Power Indicator 12
	CONNECTING TWO PCs to		PowerManager 19, 31,32
	THE MONITOR 35		Power-save Setup 31
	Contrast 19, 25,26		PRECAUTIONS 4
	Controls & Connectors 12		Preset Timing Charti
	Custom Mode 19	_	Treset riming Ghart
D		R	
	Default setting 45		Range Adjustment 19,29
	Dimensionsiv		Reset 19
	Displaying the low resolutions 27		Resolution 14,19, 24,26,40,44,47
	DVI 10,46		Rotate 19
	DVI-DMPM 19,32,46	S	
	211 2111 111		Saturation 19, 30
_			Save 18, 19
Ε			Screen 19, 23
	EIZO LCD utility disk 11, 22		Screen Adjustment 22
	EIZO Logo Disappearing function 20		Screen Size 19, 27
	EIZO MPMS 19, 31,46		ScreenManager 18
G			ScreenManager Adjustments
	Gain 19, 30,46		and Settings 19
	GLOSSARY 46		Security Lock Slot 13
	525567 II ()		Signal Filter 19, 41
Н			Smoothing 19, 28
	Height Adjustable Stand 10, 13		SPECIFICATIONS 44
	How to use the ScreenManager 18	Т	
	Hue 19, 30	•	Tomporatura 40.00.47
I			Temperature 19, 29,47
	Information 19		TMDS 10,47 Translucent 19
	Input Priority 19, 36		
	10,00		TROUBLE SHOOTING 39

U USB ----- 10,31,33,44 VESA DPMS------ 19,31,47

MEMO

APPENDIX / ANHANG / ANNEXE

Preset Timing Chart for Analog input Timing-Übersichten für Analog Eingang Synchronisation des Signaux pour Analog numerique

Based on the signal diagram shown below 23 factory presets have been registered in the monitor's microprocessor.

Der integrierte Mikroprozessor des Monitors unterstützt 23 werkseitige Standardeinstellungen (siehe hierzu die nachfolgenden Diagramme).


23 signaux ont été enregistrés en usine dans le microprocesseur du moniteur, conformément au diagramme de synchronisation ci-dessous.

	1		
Α	Front Porch	Vordere Schwarzschulter	Front avant
В	Sync Period	Synchronimpuls	Délai de synchronisation
С	Back Porch	Hintere Schwarzschulter	Front arrière
D	Blanking Period	Austastzeit	Délai de clignotement
Е	Display period	Display-Zeit	Délai d'affichage
F	Total cycle	Kompletter Zyklus	Cycle total
Н	Sync signal level	Sync-Signalpegel	Niveau du signal de synchronisation
V	Video signal level	Video-Signalpegel	Niveau du signal vidéo

Mode	Dot Clock	Frequ	encies	A: Front	Porch	B: Sync	Period
	MHz	H kHz	V Hz	H µs/ Dot	V ms/ Line	Η μs/ Dot	V ms/ Line
VGA 640 x 480	25.175	31.468	59.941	0.636/ 16	0.318/ 10	3.813/ 96	0.054/ 2
VGA 720 x 400	28.322	31.468	70.087	0.636/ 18	0.381/ 12	3.813/ 108	0.064/ 2
Macintosh 640 x 480	30.24	35.00	66.67	2.116/ 64	0.086/ 3	2.116/ 64	0.086/ 3
Macintosh 832 x 624	57.28	49.73	74.55	0.559/ 32	0.020/ 1	1.117/ 64	0.060/ 3
Macintosh 1152 x 870	100.0	68.68	75.06	0.320/ 32	0.044/ 3	1.280/ 128	0.044/ 3
VESA 640 x 480	31.5	37.86	72.81	0.508/ 24	0.026/ 9	1.270/ 40	0.079/ 3
VESA 640 x 480	31.5	37.5	75.00	0.508/ 16	0.027/ 1	2.032/ 67	0.080/ 3
VESA 640 x 480	36.0	43.27	85.01	1.556/ 56	0.023/ 1	1.556/ 56	0.069/ 3
VESA 800 x 600	36.0	35.16	56.25	0.667/ 24	0.028/ 1	2.000/ 72	0.057/ 2
VESA 800 x 600	40.0	37.88	60.32	1.000/ 40	0.026/ 1	3.200/ 128	0.106/ 4
VESA 800 x 600	50.0	48.08	72.19	1.120/ 56	0.770/ 37	2.400/ 120	0.125/ 6
VESA 800 x 600	49.5	46.88	75.00	0.323/ 16	0.021/ 1	1.616/ 80	0.064/ 3
VESA 800 x 600	56.25	53.674	85.061	0.569/ 32	0.019/ 1	1.138/ 64	0.056/ 3
VESA 1024 x 768	65.0	48.36	60.00	0.369/ 24	0.062/ 3	2.092/ 136	0.124/ 6
VESA 1024 x 768	75.0	56.48	70.07	0.320/ 24	0.053/ 3	1.813/ 136	0.106/ 6
VESA 1024 x 768	78.75	60.02	75.03	0.203/ 16	0.017/ 1	1.219/ 96	0.050/ 3
VESA 1024 x 768	94.5	68.68	85.0	0.508/ 48	0.015/ 1	1.016/ 96	0.044/ 3
Workstation 1152 x 900	94.2	61.974	66.141	0.425/ 40	0.032/ 2	1.359/ 128	0.065/ 4
Workstation 1152 x 900	107.50	71.858	76.202	0.223/ 24	0.028/ 2	1.265/ 136	0.111/ 8
Macintosh 1280 x 960	126.2	74.763	74.763	0.190/ 24	0.013/ 1	1.204/ 152	0.040/ 3
VESA 1280 x 1024	108.0	63.98	60.02	0.444/ 48	0.016/ 1	1.037/ 112	0.047/ 3
Workstation 1280 x 1024	117.0	71.691	67.189	0.205/ 24	0.028/ 2	0.957/ 112	0.112/ 8
VESA 1280 x 1024	135.0	79.97	75.02	0.119/ 16	0.013/ 1	1.067/ 144	0.038/ 3


C: Bac	k Porch	D: Blanki	ng Period	E:Display Period		F:Total Cycle	
Н	V	Н	V	Н	V	Н	V
μs/	ms/	μs/	ms/	μs/	ms/	μs/	ms/
Dot	Line	Dot	Line	Dot	Line	Dot	Line
1.907/	1.048/	6.356/	1.430/	25.442/	15.254/	31.778/	16.683/
48	33	160	45	640	480	800	525
1.907/	1.111/	6.356/	1.556/	25.422/	12.712/	31.778/	14.267/
54	35	180	49	720	400	900	449
3.175/	1.114/	7.407/	1.286/	21.164/	13.714/	28.571/	15.000/
96	39	224	45	640	480	864	525
3.911/	0.784/	5.586/	0.865/	14.524/	12.549/	20.111/	13.414/
224	39	320	43	832	624	1152	667
1.440/	0.568/	3.040/	0.655/	11.520/	12.667/	14.560/	13.322/
144	39	304	45	1152	870	1456	915
3.810/	0.528/	5.587/	0.634/	20.317/	12.678/	26.413/	13.735/
128	28	192	40	640	480	832	520
3.810/	0.427/	6.349/	0.533/	20.317/	12.800/	26.667/	13.333/
120	16	200	20	640	480	840	500
2.222/	0.578/	5.333/	0.670/	17.778/	11.093/	23.111/	11.764/
80	25	192	29	640	480	832	509
3.556/	0.626/	6.222/	0.711/	22.222/	17.067/	28.444/	17.778/
128	22	224	25	800	600	1024	625
2.200/	0.607/	6.400/	0.739/	20.000/	15.840/	26.400/	16.579/
88	23	256	28	800	600	1056	628
1.280/	0.478/	4.800/	1.373/	16.000/	12.480/	20.800/	13.853/
64	23	240	66	800	600	1040	666
3.232/	0.448/	5.172/	0.533/	16.162/	12.800/	21.333/	13.333/
160	21	256	25	800	600	1056	625
2.702/	0.503/	4.409/	0.578/	14.222/	11.179/	18.631/	11.756/
152	27	248	31	800	600	1048	631
2.462/	0.600/	4.923/	0.786/	15.754/	15.880/	20.677/	16.666/
160	29	320	38	1024	768	1344	806
19.20/	0.513/	4.053/	0.673/	13.653/	16.599/	17.707/	14.272/
144	29	304	38	1024	768	1328	806
2.235/	0.466/	3.657/	0.533/	13.003/	12.795/	16.660/	13.328/
176	28	288	32	1024	768	1312	800
2.201/	0.524/	3.725/	0.582/	10.836/	11.183/	14.561/	11.765/
208	36	352	40	1024	768	1376	808
2.123/	0.500/	3.907/	0.597/	12.229/	14.522/	16.136/	15.119/
200	31	368	37	1152	900	1520	937
1.712/	0.459/	3.200/	0.598/	10.716/	12.525/	13.916/	13.123/
184	33	344	43	1152	900	1496	943
1.838/	0.482/	3.233/	0.535/	10.143/	12.841/	13.376/	13./376
232	36	408	40	1280	960	1688	1000
2.296/	0.594/	3.778/	0.656/	11.852/	16.005	15.630/	16.661/
248	38	408	42	1280	1024	1688	1066
1.846/	0.460/	3.009/	0.600/	10.940/	14.283/	13.949/	14.883/
216	33	352	43	1280	1024	1632	1067
1.837/	0.475/	3.022/	0.525/	9.481/	12.804/	12.504/	13.329/
248	38	408	42	1280	1024	1688	1066

Dimensions Abmessungen Dimensions



Pin Assignment Pin-Belegung Affectation des Broches

* DVI-I Connector



Pin No.	Signal	Pin No.	Signal	Pin No.	Signal
1	TMDS Data2-	11	TMDS Data1/3 Shield	21	NC
2	TMDS Data2+	12	NC	22	TMDS Clock Shield
3	TMDS Data2/4 Shield	13	NC	23	TMDS Clock+
4	NC*	14	+5V Power	24	TMDS Clock-
5	NC	15	Ground (return for +5V, Hsync and Vsync)	C1	Analog Red
6	DDC Clock (SCL)	16	Hot Plug Detect	C2	Analog Green
7	DDC Data (SDA)	17	TMDS Data0-	C3	Analog Blue
8	Analog Vertical Sync	18	TMDS Data0+	C4	Analog Horizontal Sync
9	TMDS Data1-	19	TMDS Data0/5 Sheild	C5	Analog Ground (analog R,G,&B return)
10	TMDS Data1+	20	NC		

(*NC: No Connection)

* USB ports

Upstream
2 1
3

(Series B connector)

1 2 3 4 (Series A connector)

Downstream

No.	Signal	Comments
1	VCC	Cable power
2	- Data	Serial data
3	+ Data	Serial data
4	Ground	Cable Ground



Congratulations!

You have just purchased a TCO'99 approved and labelled product! Your choice has provided you with a product developed for professional use. Your purchase has also contributed to reducing the burden on the environment and also to the further development of environmentally adapted electronics products.

Why do we have environmentally labelled computers?

In many countries, environmental labelling has become an established method for encouraging the adaptation of goods and services to the environment. The main problem, as far as computers and other electronics equipment are concerned, is that environmentally harmful substances are used both in the products and during their manufacture. Since it is not so far possible to satisfactorily recycle the majority of electronics equipment, most of these potentially damaging substances sooner or later enter nature.

There are also other characteristics of a computer, such as energy consumption levels, that are important from the viewpoints of both the work (internal) and natural (external) environments. Since all methods of electricity generation have a negative effect on the environment (e.g. acidic and climate-influencing emissions, radioactive waste), it is vital to save energy. Electronics equipment in offices is often left running continuously and thereby consumes a lot of energy.

What does labelling involve?

This product meets the requirements for the TCO'99 scheme which provides for international and environmental labelling of personal computers. The labelling scheme was developed as a joint effort by the TCO (The Swedish Confederation of Professional Employees), Svenska Naturskyddsforeningen (The Swedish Society for Nature Conservation) and Statens Energimyndighet (The Swedish National Energy Administration).

Approval requirements cover a wide range of issues: environment, ergonomics, usability, emission of electric and magnetic fields, energy consumption and electrical and fire safety.

The environmental demands impose restrictions on the presence and use of heavy metals, brominated and chlorinated flame retardants, CFCs (freons) and chlorinated solvents, among other things. The product must be prepared for recycling and the manufacturer is obliged to have an environmental policy which must be adhered to in each country where the company implements its operational policy.

The energy requirements include a demand that the computer and/or display, after a certain period of inactivity, shall reduce its power consumption to a lower level in one or more stages. The length of time to reactivate the computer shall be reasonable for the user.

Labelled products must meet strict environmental demands, for example, in respect of the reduction of electric and magnetic fields, physical and visual ergonomics and good usability.

Below you will find a brief summary of the environmental requirements met by this product.

The complete environmental criteria document may be ordered from:

TCO Development

SE-114 94 Stockholm, Sweden

Fax: +46 8 782 92 07

Email (Internet): development@tco.se

Current information regarding TCO'99 approved and labelled products may also be obtained via the Internet, using the address: http://www.tco-info.com/

Environmental requirements

Flame retardants

Flame retardants are present in printed circuit boards, cables, wires, casings and housings. Their purpose is to prevent, or at least to delay the spread of fire. Up to 30% of the plastic in a computer casing can consist of flame retardant substances. Most flame retardants contain bromine or chloride, and those flame retardants are chemically related to another group of environmental toxins, PCBs. Both the flame retardants containing bromine or chloride and the PCBs are suspected of giving rise to severe health effects, including reproductive damage in fish-eating birds and mammals, due to the bio-accumulative* processes. Flame retardants have been found in human blood and researchers fear that disturbances in foetus development may occur.

The relevant TCO'99 demand requires that plastic components weighing more than 25 grams must not contain flame retardants with organically bound bromine or chlorine. Flame retardants are allowed in the printed circuit boards since no substitutes are available.

Cadmium**

Cadmium is present in rechargeable batteries and in the colour-generating layers of certain computer displays. Cadmium damages the nervous system and is toxic in high doses. The relevant TCO'99 requirement states that batteries, the colour-generating layers of display screens and the electrical or electronics components must not contain any cadmium.

Mercury**

Mercury is sometimes found in batteries, relays and switches. It damages the nervous system and is toxic in high doses. The relevant TCO'99 requirement states that batteries may not contain any mercury. It also demands that mercury is not present in any of the electrical or electronics components associated with the labelled unit.

CFCs (freons)

The relevant TCO'99 requirement states that neither CFCs nor HCFCs may be used during the manufacture and assembly of the product. CFCs (freons) are sometimes used for washing printed circuit boards. CFCs break down ozone and thereby damage the ozone layer in the stratosphere, causing increased reception on earth of ultraviolet light with e.g. increased risks of skin cancer (malignant melanoma) as a consequence.

Lead**

Lead can be found in picture tubes, display screens, solders and capacitors. Lead damages the nervous system and in higher doses, causes lead poisoning. The relevant TCO'99 requirement permits the inclusion of lead since no replacement has yet been developed.

- * Bio-accumulative is defined as substances which accumulate within living organisms.
- ** Lead, Cadmium and Mercury are heavy metals which are Bio-accumulative.

For U.S.A, Canada, etc. (rated 100-120 Vac) Only

FCC Declaration of Conformity

We, the Responsible Party <u>EIZO NANAO TECHNOLOGIES INC.</u>

5710 Warland Drive, Cypress, CA 90630

Phone: 562 431 5011

declare that the product Trade name: EIZO

Model: FlexScan L675

is in conformity with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provid reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- *Reorient or relocate the receiving antenna.
- *Increase the separation between the equipment and receiver.
- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- *Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note

Use the attached specified cable below or EIZO signal cable with this monitor so as to keep interference within the limits of a Class B digital device.

- -AC Cord
- -Shielded Signal Cable (enclosed)

Canadian Notice

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de le classe B est comforme à la norme NMB-003 du Canada.